

AUTOLIFT SYSTEM

INSTALLATION MANUAL FOR ADAPTER

MERCEDES BENZ SPRINTER FRONT WHEEL DRIVE



Front Left adapter Mercedes

Step 1:

Insert the plates in the holes



Step 2:



Insert the adapter in the space present on the chassis and push most frontly possible.

Step 3:



Fit the adapter with the bolts supplied

Front Right adapter Mercedes

Step 1 – 2 – 3:



Follow the same procedure of the front left adapter

**JACK WITH MOTOR TO THE OUTSIDE OF THE VEHICLE AND
ROTATION REAR**



EXAMPLES OF JACKS CORRECTLY INSTALLED

Rear left adapter Mercedes

Step 1:



Put the adapter in the point illustrated, the rear support of the crossbow suspension

Step 2:



Insert the special plates and fix the adapter with the M8 bolts supplied



Step 3:



Fix the jack.

USE THE SAME PROCEDURE FOR THE REAR RIGHT ADAPTER

JACKS WITH MOTOR TO THE OUTSIDE OR INSIDE OF THE VEHICLE AND ROTATION REAR