




## LEVELLING

### THE AUTOLIFT 5 EASY STEPS TO LEVELLING YOUR CARAVAN

1. When finding the ideal site for your caravan, ensure there are no obstacles such as logs or rocks that could impede levelling.
2. Unhitch the van from your vehicle using your jockey wheel/stand.
3. Once you have unhitched from your vehicle you **must** use the jockey wheel/stand to adjust the height of the front end so that the **chassis is parallel to the ground**. This is to ensure an equal distance of height is achieved both front and rear of the axle. See examples below.



4. Check again that there are no obstructions that could interfere with deployment of the jacks.
5. Push the 'Start' button and then 'Auto' button on the keypad to level. To prevent sinking on soft ground, you can use pads under each jack leg once the jacks have been deployed.

WE HOPE YOU ENJOY YOUR LEVELLING EXPERIENCE!