

AUTOLIFT SYSTEM

INSTALLATION MANUAL FOR
ADAPTERS **MERCEDES 316/417/419**
since 2016

Please subscribe to our Youtube channel TESA AUTOLIFT SYSTEM and see all tutorial videos.

Front left adapter Mercedes 316/417/419



Step 1: Insert the special plate in the hole present on the frame, put the adapter and push frontly.



Step 2: Then fix the adapter with the bolt M10 supplied.



USE THE SAME PROCEDURE FOR THE FRONT
RIGHT ADAPTER

A close-up photograph of the hydraulic cylinder actuator. A hand is pointing to the top of the cylinder. The actuator is a silver, cylindrical component with a label that includes the text "CE 00120" and a table of specifications. The table lists the following data:

Model	Stroke	Weight
5010 5010	100 mm	1.2 kg
5010 5010	150 mm	1.5 kg
5010 5010	200 mm	1.8 kg
5010 5010	250 mm	2.1 kg
5010 5010	300 mm	2.4 kg
5010 5010	350 mm	2.7 kg
5010 5010	400 mm	3.0 kg
5010 5010	450 mm	3.3 kg
5010 5010	500 mm	3.6 kg
5010 5010	550 mm	3.9 kg
5010 5010	600 mm	4.2 kg
5010 5010	650 mm	4.5 kg
5010 5010	700 mm	4.8 kg
5010 5010	750 mm	5.1 kg
5010 5010	800 mm	5.4 kg
5010 5010	850 mm	5.7 kg
5010 5010	900 mm	6.0 kg
5010 5010	950 mm	6.3 kg
5010 5010	1000 mm	6.6 kg



A hand is pointing to a blue and silver electronic control unit (ECU) mounted on a vehicle chassis. The unit has a blue label with white text that reads "CE 00120" and "2010 2010 2010 2010 2010 2010". The unit is connected to various wires and components. The chassis is painted blue and has a white label with the number "5" in a black box.

Rear left adapter Mercedes 316/417/419

Step 1:



Put the adapter in the point illustrated, the rear support of the crossbow suspension

Step 2:



Insert the special plates and fix the adapter with the M8 bolts supplied



Step 3:



Fix the jack.

USE THE SAME PROCEDURE FOR THE REAR RIGHT ADAPTER

JACKS WITH MOTOR TO THE OUTSIDE OR INSIDE OF THE VEHICLE AND ROTATION REAR